



**Assemble Step:**

1. Use the M6\*12 hexagonal socket B head screws and flange nuts to connect the top and bottom beam ,side posts ,and the bottom base together.
2. Use the M5\*8 Phillips pan head tapping screw to attach the castors to the bottom base.

**MAIN PAPT:**

1. Top and bottom beam
2. Side post
3. Bottom base
4. Castor

